

Thermal anemometer

testo 425 - With fixed flow velocity
probe

-
- Measurement of flow velocity, volume flow and temperature

 - Point and timed mean value calculation

 - Max./min. values

 - Hold button for freezing measurement value

 - Display illumination

 - Auto-off function

 - TopSafe, protection of the instrument from dirt and impact (optional)



testo 425 is a compact anemometer with a fixed thermal flow velocity probe. The probe head has a diameter of 7.5 mm. With the extendable telescope (length max. 820 mm), the measuring instrument is suitable for flow velocity measurement in ducts. The testo 425 also measures extremely accurately in the low flow velocity range. The volume flow is directly shown in the display. For the purposes of volume flow calculation, the duct area can be

easily entered into the testo 425. In addition to this, the instrument can be switched over to display the current temperature. Timed and point mean value calculation provide information on the average volume flow, flow velocity and temperature measurement value. The Hold function allows the current measurement value to be frozen in the display, min./max. values are also displayed at the press of a button.

Technical data / Accessories

testo 425

testo 425 compact thermal anemometer with fixed velocity probe incl. temperature measurement and telescope (max. 820 mm), battery and calibration protocol

Part no. 0560 4251



General technical data

Operating temperature	-20 to +50 °C
Storage temperature	-40 to +85 °C
Battery type	9V block battery, 6F22
Battery life	20 h
Dimensions	182 x 64 x 40 mm
Weight	285 g
Housing material	ABS
Warranty	2 years

Sensor types

	Thermal	NTC
Measuring range	0 to +20 m/s	-20 to +70 °C
Accuracy ±1 digit	±(0.03 m/s +5% of m.v.)	±0.5 °C (0 to +60 °C) ±0.7 °C (remaining range)
Resolution	0.01 m/s	0.1 °C

Accessories

Part no.

Case for measuring instrument and probes	0516 0210	
TopSafe, protects from impact and dirt	0516 0221	
Service case for measuring instrument and probe, dimensions 454 x 316 x 111 mm	0516 1201	
Recharger for 9V rechargeable battery, for external recharging of 0515 0025 battery	0554 0025	
9V rech. battery for instrument, instead of battery	0515 0025	
ISO calibration certificate velocity hot wire, vane anemometer, Pitot tube; calibration points 1; 2; 5; 10 m/s	0520 0004	
ISO calibration certificate velocity hot wire, vane anemometer, Pitot tube; calibration points 5; 10; 15; 20 m/s	0520 0034	
ISO calibration certificate velocity hot wire, vane anemometer; calibration points 0.3; 0.5; 0.8; 1.5 m/s	0520 0024	

0981 9664/msp/A/08.2015

Subject to change without notice.

Testo India Pvt Ltd

Head Office:

Plot No. 23, Sindh Society, Baner Road,
Aundh, Pune - 411007, Maharashtra, India
Tel: +91 20 6560 0203 | Fax: +91 20 2585 0080
Email: info@testoindia.com | Web: www.testo.in

Regional Offices / Representatives:

Ahmedabad | Baroda | Bengaluru | Chandigarh | Chennai | Guwahati
Hyderabad | Indore | Kolkata | Mumbai | New Delhi | Raipur

Authorized Channel Partner

Sunshine Instruments
83, Chinnys Chamber,
Dr. Nanjappa road,
Coimbatore - 641 018 Tamil Nadu
Tel: +91 422 2393357 / +91 9360023357
Email: instrumentsindia2012@gmail.com
Branch Office : MUMBAI