



725 Pocket Combustible Gas Detector

APPLICATIONS

- Trace natural gas lines and fittings for leaks.
- Check gas applications for leaks.
- Check propane tanks, fitting lines, and heaters for leaks.
- Check gas generators for fuel leaks.
- Test confined spaces for gas build-up.



Actual size

725 Features

- Detects Combustible Gases Including: Natural Gas, Methane, Butane, Propane(LPG), Gasoline, Diesel, and Kerosene
- Fits in shirt pocket
- Auto zeros
- Visual and audible alarm
- Responds instantly

LEAK LEVELS



Level 4: > 5,000ppm Methane
 Level 3: > 4,000ppm Methane
 Level 2: > 2,000ppm Methane
 Level 1: > 1,000ppm Methane
 Power: Green = Ready
 Red = Replace Batteries

Turn over for technical information and accessory part numbers.

The Value Leader™

OPERATING INSTRUCTIONS

- Remove sensor cap
- Press ON/OFF button
- LEDs will flash as the unit initializes; when the green LED above the ON/OFF button is lit, the unit is ready
- Upon detection an alarm will sound & the red LED will indicate the severity of the leak



visit us at www.tpi-thevalueleader.com



725 Pocket Combustible Gas Detector

TECHNICAL SPECIFICATIONS AND ACCESSORIES

- Digital
- Multimeters •
- Clamp Meters •
- Hand-held
- Oscilloscopes •
- Refrigerant & Combustible Gas Leak Detectors •
- Temperature Testers •
- BNC Coax Cable •
- Connectors •
- Test Leads •
- Accessories

Test Products International, Inc.
 Headquarters:
 9615 SW Allen Blvd.
 Beaverton, OR 97005
 USA
 503-520-9197
 Fax: 503-520-1225
 email:
 info@tpi-the value leader.com

Test Products International, Ltd.
 342 Bronte St. South
 Unit 9
 Milton, Ontario L9T
 5B7
 Canada
 905-693-8558
 Fax: 905-693-0888
 email:
 info@tpicanada.com

Test Products International UK Ltd.
 Longley House, East Park
 Crawley, West Sussex
 RH10 6AP England
 Tel: +44 (0)1293 561212
 Fax: +44 (0)1293813465
 contact us@tpieurope.com

Instrument Specifications

Sensitivity:	> 1,000ppm combustible gas (Methane)
Operating Temp:	32° to 104°F (0° to 40° C)
Warm-up:	7-10 seconds
Response Time:	Instantaneous
Battery:	Two AAA
Power Consumption:	DC 20mA
Battery Life:	3 continuous hours
Overall Dimensions:	1.38" 5.0" x 0.75" (34.9 x 127 x 19.1)
Weight:	0.30 lb. (0.14 kg.)

Distributed By:



To learn about the entire line of TPI products visit:

www.tpi-thevalueleader.com

L 725-1104
 Copyright © 2004 Test Products International, Inc.