

*-3,000 mG to 3,000 mG, -300.0 uT to 300.0 uT, AC/*



# PRECISION MILLI GAUSS METER

Model : GU-3001

*ISO-9001, CE, IEC1010*



LUTRON ELECTRONIC

*The Art of Measurement*



*DC/AC milligauss magnetometer*

# PRECISION MILLI GAUSS METER

**Model : GU-3001**

## FEATURES

* DC/AC milligauss Magnetometer.
* Using exclusive high sensitivity sensor ( better performance than the traditional Hall element sensor ), available for high precision magnetic field measurement.
* Wide application for industrial, mechanical, material, electrical, laboratory field to check the material contains magnetic field value.
* DC and AC magnetic field measurement
* Wide measure range : $\pm 3,000$ milligauss.
* The meter can detect the magnetic fields as small as 0.1 milligauss.
* N pole/S pole indicator.
* Separate probe, easy operation and convenient for remote measurement.
* High precision magnetometer, even can measure the absolute environment Earth's magnetic field as reference.
* Zero adjustment button for relative measurement.
* Large S-TN type LCD, high contrast, easy readout.
* Data hold function for freezing the desired value on display.
* Records Maximum and Minimum readings with Recall.
* RS232/USB computer interface.
* Microprocessor circuit assures maximum possible accuracy, provides special functions and features.
* Heavy duty & compact housing with hard carrying case, designed for easy carry out & operation.
* Auto shut off is available to save battery life.
* Power supply from batteries or DC 9V adapter in.

## SPECIFICATIONS

Circuit	Custom one-chip of microprocessor LSI circuit.
Display	LCD size : 52 mm x 38 mm dual function LCD display.
Measurement Unit	mG : milligauss uT : micro Tesla
Measurement Range	- 3,000 mG to 3,000 mG. - 300 uT to 300 uT.
Frequency	DC
Response	AC : 40 Hz to 10 KHz

Resolution	0.1 mG	- 199.9 mG to 199.9 mG.
	1 mG	$\geq 200$ mG, $\leq -200$ mG
	0.01 uT	- 19.99 uT to 19.99 uT.
	0.1 uT	$\geq 20.0$ uT, $\leq -20.0$ uT.
Accuracy	$\pm (2\% \text{ FS} + 2 \text{ mG})$ * FS: FULL SCALE	
Field Direction	Uni-axial.	
Data Hold	Freeze the display reading.	
Memory Recall	Maximum & Minimum value.	
Display	Approx. 1 second.	
Sampling Time		
Power off	Manual off by push button or Auto shut off to save battery life.	
Data Output	RS 232/USB PC serial interface. * Connect the optional RS232 cable UPCB-02 will get the RS232 plug. * Connect the optional USB cable USB-01 will get the USB plug.	
Operating Temperature	0 to 50 °C.	
Operating Humidity	Less than 85% R.H.	
Power Supply	DC 1.5 V battery ( UM4, AAA ) x 6 PCs, Alkaline/heavy duty type or equivalent.	
Power Current	Approx. DC 20.5 mA .	
Weight	Main instrument : 321 g/0.71 LB. @ Battery is included. Probe : 78 g/0.17 LB.	
Dimension	Main instrument : 173 x 68 x 42 mm (7.9 x 2.7 x 1.2 inch) Probe : 177 x 29 x 17 mm	
Accessories Included	Instruction manual..... 1 PC Probe..... 1 PC Hard Carrying case, CA-06..... 1 PC	
Optional Accessories	RS232 cable, UPCB-02 USB cable, USB-01 Data Acquisition software, SW-U801-WIN	

\* Appearance and specifications listed in this brochure are subject to change without notice.

2212-GU3001