

**SD Card, real time data logger, Patent
Frequency and Time weighting meet IEC 61672 clas**



SOUND LEVEL METER

Model : SL-4033SD

ISO-9001, CE, IEC1010



Hard carrying case, CA-06



Lutron

LUTRON ELECTRONIC

The Art of Measurement

SD Card real time data logger SOUND LEVEL METER Model : SL-4033SD



FEATURES

* Frequency and time weighting meet IEC 61672 class 1
* A & C weighting networks comply with standards.
* 0.5" standard microphone head.
* Time weighting (Fast & Slow) dynamic characteristic modes.
* Build External calibration VR.
* Auto range & Manual range selection.
* Available for external calibration adjustment.
* Condenser microphone for high accuracy & long-term stability.
* Memory function to store the Max. & Min. value.
* Hold and Peak Hold functions.
* Real time SD memory card Datalogger, it Built-in Clock and Calendar, real time data recorder, sampling time set from 1 second to 3600 seconds.
* Manual datalogger is available (set the sampling time to 0 second), during execute the manual datalogger function, it can set the different position (location) No. (position 1 to position 99).
* Innovation and easy operation, computer is not need to setup extra software, after execute datalogger, just take away the SD card from the meter and plug in the SD card into the computer, it can down load the all the measured value with the time information (year/month/date/hour/minute/second) to the Excel directly, then user can make the further data or graphic analysis by themselves.
* SD card capacity : 1 GB to 16 GB.
* LCD with green light backlight, easy reading.
* Can default auto power off or manual power off.
* Data hold, record max. and min. reading.
* Microcomputer circuit, high accuracy.
* Power by UM3/AA (1.5 V) x 6 batteries or DC 9V adapter.
* RS232/USB PC COMPUTER interface.
* Heavy duty & compact housing case.

GENERAL SPECIFICATIONS

Circuit	Custom one-chip of microprocessor LSI circuit.																																	
Display	LCD size : 52 mm x 38 mm LCD with green backlight (ON/OFF).																																	
Measurement Range	30 - 130 dB.																																	
Resolution	0.1 dB.																																	
Function	dB (A & C frequency weighting), Time weighting (Fast, Slow), Peak hold, Data hold. Record (Max., Min.).																																	
Accuracy (23 ± 5 °C)	Characteristics of " A " frequency weighting network meet IEC 61672-1-2013 class 1 Under 94 dB input signal, the accuracy are : <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>31.5</td><td>Hz</td><td>reading ±1.5 dB</td></tr> <tr><td>63</td><td>Hz</td><td>reading ±1.0 dB</td></tr> <tr><td>125</td><td>Hz</td><td>reading ±1.0 dB</td></tr> <tr><td>250</td><td>Hz</td><td>reading ±1.0 dB</td></tr> <tr><td>500</td><td>Hz</td><td>reading ±1.0 dB</td></tr> <tr><td>1 K</td><td>Hz</td><td>reading ±0.7 dB</td></tr> <tr><td>2 K</td><td>Hz</td><td>reading ±1.0 dB</td></tr> <tr><td>4 K</td><td>Hz</td><td>reading ±1.0 dB</td></tr> <tr><td>8 K</td><td>Hz</td><td>reading +1.5 dB, -2.5dB</td></tr> <tr><td>12.5 K</td><td>Hz</td><td>reading +2.0 dB, -5.0dB</td></tr> <tr><td>16 K</td><td>Hz</td><td>reading +2.5 dB, -16.0dB</td></tr> </table> Remark : The above spec. are tested under the environment RF Field Strength less than 3 V/M & frequency less than 30 MHz only.	31.5	Hz	reading ±1.5 dB	63	Hz	reading ±1.0 dB	125	Hz	reading ±1.0 dB	250	Hz	reading ±1.0 dB	500	Hz	reading ±1.0 dB	1 K	Hz	reading ±0.7 dB	2 K	Hz	reading ±1.0 dB	4 K	Hz	reading ±1.0 dB	8 K	Hz	reading +1.5 dB, -2.5dB	12.5 K	Hz	reading +2.0 dB, -5.0dB	16 K	Hz	reading +2.5 dB, -16.0dB
31.5	Hz	reading ±1.5 dB																																
63	Hz	reading ±1.0 dB																																
125	Hz	reading ±1.0 dB																																
250	Hz	reading ±1.0 dB																																
500	Hz	reading ±1.0 dB																																
1 K	Hz	reading ±0.7 dB																																
2 K	Hz	reading ±1.0 dB																																
4 K	Hz	reading ±1.0 dB																																
8 K	Hz	reading +1.5 dB, -2.5dB																																
12.5 K	Hz	reading +2.0 dB, -5.0dB																																
16 K	Hz	reading +2.5 dB, -16.0dB																																
Frequency Weighting Network	Characteristics of A & C. A weighting : The characteristic is simulated as "Human Ear Listening" response. Typical, if making the environmental sound level measurement, always select to A weighting. C weighting The characteristic is near the "FLAT" response. Typical, it is suitable for checking the noise of machinery (Q.C. check) & knowing the sound pressure level of the tested equipment.																																	

Peak hold	To keep the peak (max.) measurement value.
Time weighting (Fast & Slow)	Fast - t = 125 ms * "Fast" range is simulated the human ear response time weighting. Slow - t = 1 Sec. * "Slow" range is easy to get the average values of vibration sound level.
Range selector	Auto range : 30 to 130 dB. Manual range : 3 range, 30 to 80 dB, 50 to 100 dB, 80 to 130 dB, 50 dB on each step, with over & under range indicating.
Frequency	31.5 to 16 KHz.
Microphone type	Electric condenser microphone.
Microphone size	Out size, 12.7 mm DIA. (1/2 inch).
Calibration VR	Build in external calibration VR, easy to calibrate on 94 dB level by screw driver. * Calibrated via external SOUND CALIBRATOR (SC-941, optional).
Calibrator	B & K (Bruel & kjaer), Multifunction Acoustic Calibrator 4226.
Datalogger	Auto 1,2,5,10,30,60,120,300,600, 1800,3600 seconds. @ If set to 1 second, memory data may loss.
Sampling Time Setting range	Manual Push the data logger button once will save data one time. @ Set the sampling time to 0 second. @ Manual mode, can also select the 1 to 99 position (Location) no.
Memory Card	SD memory card. 1 GB to 16 GB.
Advanced setting	* Set clock time (Year/Month/Date, Hour/Minute/ Second) * Decimal point of SD card setting * Auto power OFF management * Set beep Sound ON/OFF * Set sampling time * SD memory card Format
Over Indication	Show " - - - ".
Data Hold	Freeze the display reading.
Memory Recall	Maximum & Minimum value.
Sampling Time of Display	Approx. 1 second.
Data Output	RS 232/USB PC computer interface. * Connect the optional RS232 cable UPCB-02 will get the RS232 plug. * Connect the optional USB cable USB-01 will get the USB plug.
Power off	Auto shut off (approx. 10 minutes) saves battery life or manual off by push button.
Operating Temperature	0 to 50 °C.
Operating Humidity	Less than 85% R.H.
Power Supply	* Alkaline or heavy duty DC 1.5 V battery. (UM3, AA) x 6 PCs, or equivalent. * DC 9V adapter input. (AC/DC power adapter is optional).
Power Current	Normal operation (w/o SD card save data and LCD Backlight is OFF) : Approx. DC 12 mA. When SD card save the data but and LCD Backlight is OFF) : Approx. DC 31 mA. * AC/DC power adapter is optional. consumption will increase approx. 8 mA.
Weight	320 g/0.70 LBS.(without battery)
Dimension	245 x 68 x 45 mm. (9.6 x 2.7x 1.8 inch).
Accessories Included	* Instruction manual.....1.PC * Hard carrying case, CA-06.....1 PC
Optional Accessories	* Sound calibrator (94 dB), SC-941. * Sound calibrator (94/114 dB), SC-942. * Sound wind shield ball, SB-01. * SD Card * USB cable, USB-01. * RS232 cable, UPCB-02. * Data Acquisition software, SW-U801-WIN. * AC to DC 9V adapter. * Soft carrying case, CA-05A.

PATENT	CHINA : ZL 2008 2 0189918.5 ZL 2008 2 0189917.0 TAIWAN : M 358970 M 359043 Germany : Nr. 20 2008 016 337.4 JAPAN : 3151214 U.S.A. : Pending
--------	--

* Appearance and specifications listed in this brochure are subject to change without notice. 200407-SL4033SD