



# AT-5 Engine Tachometer

The CEM AT-5 is an engine tachometer that can be used on various types of engines to check the RPM of the engines, be it 2 stroke engines or 4 stroke engines. The AT-5 can measure the RPM of the engine by bringing it close to the plug chord of the engine.

It has many measurement modes for various engines like 2 Stroke (1 and 4 cylinder) and 4 stroke (1,6 and 8 cylinders).

It also comes with an antenna lead which can be used if needed.

### SPECIFICATIONS

- Display : 6 digits LCD display
- Accuracy : ±10 RPM
- RPM display interval : 0.5sec
- Dimensions : (L x W x H) 156mm\* 42mm\* 20mm\*
- Main body weight : 177g
- Accessories : Antenna lead
- Measuring method : Count pulses
- Power supply : 9V Battery
- Operation temp : 0°C to 50°C

### Rang of Measure

Measurable Engine		Measurable RPM Range
Stroke	Cylinder	
2	1	100 ~ 20000
4	2	
4	3	100 ~ 13000
2	2	100 ~ 10000
4	4	
2	3	100 ~ 6500
4	6	
4	1	100 ~ 20000
4	5	100 ~ 7000
2	4	100 ~ 4800
4	8	

